



Bios

Driving a Higher Standard
in Flow MeasurementSM

Loading Bios Optimizer Collect Methods

To install Bios Optimizer Methods and Device files from our Web site:

- Download the Method files .LIM and Instrument file .DEV from our web site and save the files to your PC
- Start Collect on your PC
- On the Collect start screen, click on Tools>Import Instrument
- Select the instrument >DEV file you downloaded
- On the Collect start screen, click on Tools>Import Method
- Select a Method .LIM file you downloaded
- Repeat for other Method files you downloaded .LIM